






0199




Position ID	Part number.	Replaces:	Description
0101	00702534		Interface
0102	00626584		Mounting bracket
0103	00626585		Mounting bracket
0104	00659197		Clamp
0105	00659198		Clamp
0106	00659199		Clamp
0107	00626586		Clip
0108	00741802		Glass panel
0109	00741804	11010329	Panel-facia
0110	00611413		Screw
0199	12016495		Adjusting device




Position ID	Part number.	Replaces:	Description
0201	00643600		Fan
0202	00612548	00617877	Fixing kit
0203	00608076		Bracket
0204	00659614	12022212	Control module
0205	00436364		Terminal box
0206	00663802		Power supply unit
0208	00676788		Plate
0209	00663795		Cable harness
0251	00652261		Cable harness
0252	00663791		Cable harness
0253	00663792		Cable harness
0254	00663925		Cable harness
0255	00663793		Cable harness
0256	00663794	11033493	Cable harness
0257	00646662		Cable harness
0259	00659203		Cable harness
0260	00614573		Screw
0261	00620814		Screw
0207	00751505		Latch
0250	00751482		Cable harness






Position ID	Part number.	Replaces:	Description
0301	00642845		Motor
0302	00491572		Catalyzer
0303	00625068		Lamp
0304	00624404		Halogen lamp
0305	00625069		Lamp
0306	00687877		Reflector
0307	00144667		Heating element
0309	00491569		Door Gasket
0310	00663805		Heating element
0311	00642855		Sensor
0313	00646291		Fan blade
0315	00478307		Ventilation duct
0316	00643000		Support
0317	00609073		Screw
0318	00144648		Heating element
0319	00612669		Socket
0320	00605039		Washer
0321	00608199		Nut
0350	00666001		Cable harness
0312	00603860		Spacer
0314	00471532		Nut
0322	00422090		Washer
0308	00427919		Spacer
0308	00631116		Spacer



Position ID	Part number.	Replaces:	Description
0401	00189345		Screw
0402	00626587		Screw
0403	00611387		Washer
0404	00626588		Screw
0405	00688495		Door-inner
0406	00741807		Door hinge
0407	00626589	00630309	Bracket
0408	00144652		Seal-door
0409	00685879	00770023	Glass panel
0410	00741810		Support
0411	00688497		Glass panel
0412	00604411		Screw
0413	00608091		Spacer
0414	00613178		Bracket
0415	00613179		Bracket
0416	00612252		Clip
0417	00246552		Door-outer
0418	00619574		Bracket
0419	00619573		Bracket
0421	00656756		Handle-cap shaped
0422	00656755		Handle-cap shaped
0423	00656869		Handle
0450	00622734		Screw



Position ID	Part number.	Replaces:	Description
0501	00248343		Cover
0502	00664290		Plate
0503	00248788		Cover
0504	00649210		Cover
0505	00644616		Flap
0506	00684096		Cover
0507	00741812	11022039	Trimplate
0508	00618862		Screw
0509	00741813	11022040	Trimplate
0510	00711267		Base
0511	00708568		Exhaust baffle
0512	00615096		Screw
0513	00741818		Air channel exhaust
0550	00600623		Screw
0551	00668853		Tubular
0552	00414692		Connection
0553	00416289		Insert
0554	00415812		Retaining washer
0555	00753600		Connection cable



Position ID	Part number.	Replaces:	Description
0603	00449756		Broiler Pan
0605	00492332	00755060	Meat Probe
0601	00685579		Wire Rack
0602	00685577		Shelf